

# Installation instructions for buffer three linkage sliding door system


### Installation instructions:


- ①The linkage sliding door system cannot be installed in all hidden slots, and the must be reserved for installation;
- ②The guide rail must be installed on steel or concrete structure beams with sufficient strength;
- ③When installing the guide rail, the guide rail must be cleaned of debris in the inner groove before it can be fitted with the roller assembly;
- ④For sliding doors are used with high frequency, we recommend that users regularly invite maintenance personnel for inspection and maintenance;


#### Installation tools:



















# 8 Install hanger locating piece


# 8-1 Right linkage






Fix the bracket fixing piece on the corresponding door according to the figure, and pay attention to the direction of the door and the distance between both sides;

## 8-2 Left linkage




Fix the bracket fixing piece on the corresponding door according to the figure, and pay attention to the direction of the door and the distance between both sides;





# 9 Install the A-door guide


# 9-1 Right linkage




# 9-2 Left linkage














#### 11-2 Left linkage












The positioning buckle L and the buffer paddle m are adjusted on site according to the actual size;



# Installation finished!